
U-Blocks

The U-Block is used to convert the external dimensions of InsertBlocks, AddBlocks and HandiBlocks to the next modular size.

For example a 30/15 InsertBlock can be enlarged by placing it into a U40, giving the new size of 40/15.















Dimensions U-BLOCK	А		В		С	
	mm	(inches)	mm	(inches)	mm	(inches)
U-30	30	1.18	20	0.79	15	0.59
U-40	40	1.57	30	1.18	20	0.79
U-60	60	2.36	40	1.57	30	1.18
U-90	90	3.54	60	2.36	45	1.77
U-120	120	4.72	90	3.54	45	1.77



Regardless of cable diameter, you can retain the outer measurement of the block in any row.

